

Directions for Pfizer Temp Tale – February 3, 2020

- Upon receipt of the Pfizer cooler, press and hold the stop button on the digital data logger for 5 seconds.
- The data logger will display 3 green lights once turned off (see image below)



- Your data logger may display red lights once turned off as well (see image below)



- If Shipment Status displays red, contact Controlant as your shipment may have experienced a temperature excursion.
- If Connection displays red, contact Controlant as the shipper may have been out of Wifi range, and you may need to verify cold-chain.
- If the Battery displays red (see image 2), the temp tale has low battery and should be returned to Pfizer as soon as possible.
- If you have any questions regarding cold chain with the Pfizer shipper, email Controlant at onsitemonitoring@controlant.com with the Data Logger ID Number (CMS #) displayed on the bottom left of the data logger. Answers from Controlant may be delayed as their main office is located in Iceland.